

# Blind Rivets for Motorcycle Parts

Blind rivets, also known as pop rivets, are fasteners used to join materials. A tool pulls the mandrel, expanding the rivet body for a tight joint before the mandrel snaps off.



## Product Overview

### High-Performance Blind Rivets

These blind rivets, also known as pop rivets, are essential fasteners designed for securing two or more materials together efficiently. Featuring a durable rivet body and a setting mandrel, they are engineered for applications where access to the back of the joint is limited. Once installed with a specialized tool, the mandrel snaps off, ensuring a clean, finished appearance and a secure, tight joint.

## Technical Details

Fastener Type	Blind Rivet (Pop Rivet)
Primary Application	Motorcycle Parts, Automotive Assembly, Sheet Metal Joining

## Installation

### Installation Method

- Insert into pre-drilled hole
- Use specialized riveting tool
- Pull mandrel to expand rivet body
- Snap off mandrel