


Appliance Control Knobs

These control knobs are designed for use in kitchen appliances such as stoves and ovens. They are available in a variety of designs, materials, and colors to suit different appliance models.



ADDITIONAL IMAGES



Product Overview

Professional Appliance Control Knobs

This extensive collection of appliance control knobs offers a versatile solution for oven, stove, and general kitchen appliance maintenance. Designed to accommodate a wide range of control styles, these parts include options with push-button functionality, clear 'OFF' markings, and varied visual indicators. Whether you require metallic, black, or silver finishes, this selection provides the necessary replacement components to restore functionality and aesthetic consistency to your appliance inventory.

Technical Specifications

Finish Styles

Metallic • Black • Silver

Key Features

- Push-button integration
- OFF position indicators
- Diverse control styles
- Replacement-ready design

Primary Application

Electronic Oven & Kitchen Appliances

Material Composition

Plastic, Metal

Model Inventory

Model Reference Range

Series	Range
1917K Series	1917K001 - 1917K077