


# Pneumatic Tire Valve Core

Valve cores are small, spring-loaded valves used in pneumatic tires. They allow air to be inflated into the tire while preventing air from escaping.



## Product Overview

### Professional Grade Valve Core

The CPX4012 pneumatic tire valve core is a precision-engineered, spring-loaded component designed for optimal tire inflation control. Built from durable materials, this core ensures a reliable air-tight seal that prevents leakage under various operating conditions. It is an essential component for the maintenance and repair of standard pneumatic tire systems.

## Product Details

Model Number	CPX4012
Core Type	Spring-loaded pneumatic

## Construction & Compatibility

### Suitable For

- Standard pneumatic tires
- Inflation maintenance systems

Material Composition	Brass, Steel
----------------------	--------------

## Maintenance

Required Tools	Valve core removal and installation tool
----------------	--